




POWER EQUIPMENT

OWNER'S MANUAL

INDIRECT-FIRED DIESEL/KEROSENE HEATERS

Model No.: PIN HK070FWI



ASSEMBLY & OPERATION INSTRUCTIONS

V1.0 2024

INTRODUCTION

Thank you for choosing a BE product. Read this manual carefully before using the unit and save it for future reference.

Disclaimer

BE reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication.

While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.



Disposal guidelines (EU)

Do not dispose of this product with general household waste. This product must be disposed according to the laws governing Waste Electrical and Electronic Equipment. If required, contact your local authorities for information regarding the available disposal facilities.

1. GENERAL SAFETY RULES

READ INSTRUCTIONS CAREFULLY. READ AND FOLLOW ALL INSTRUCTIONS. PLACE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE. DO NOT ALLOW ANYONE WHO HAS NOT READ THESE INSTRUCTIONS TO ASSEMBLE, LIGHT, ADJUST OR OPERATE THE HEATER.

IF THE INFORMATION IN THIS MANUAL IS NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

SERVICE MUST BE PERFORMED BY A QUALIFIED SERVICE AGENCY.

UNVENTED PORTABLE HEATERS USE AIR (OXYGEN) FROM THE AREA IN WHICH IT IS USED. ADEQUATE COMBUSTION AND VENTILATION AIR MUST BE PROVIDED. REFER TO INSTRUCTIONS.

WARNING

DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

WARNING

FIRE, BURN, INHALATION, AND EXPLOSION HAZARD. KEEP SOLID COMBUSTIBLES, SUCH AS BUILDING MATERIALS, PAPER OR CARDBOARD, A SAFE DISTANCE AWAY FROM THE HEATER AS RECOMMENDED BY THE INSTRUCTIONS. NEVER USE THE HEATER IN SPACES WHICH DO OR MAY CONTAIN VOLATILE OR AIRBORNE COMBUSTIBLES, OR PRODUCTS SUCH AS GASOLINE, SOLVENTS, PAINT THINNER, DUST PARTICLES OR UNKNOWN CHEMICALS.

WARNING

WRONG EXHAUST PIPE INSTALLATION MAY CAUSE CARBON MONOXIDE (CO) POISONING, E.G INDOORS WITHOUT ADEQUATE EXHAUST CONNECTION. CO POISONING MAY LEAD TO DEATH.

GENERAL HAZARD WARNING

FAILURE TO COMPLY WITH THE PRECAUTIONS AND INSTRUCTIONS PROVIDED WITH THIS HEATER, CAN RESULT IN DEATH, SERIOUS BODILY INJURY AND PROPERTY LOSS OR DAMAGE FROM HAZARDS OF FIRE, EXPLOSION, BURN, ASPHYXIATION, CARBON MONOXIDE POISONING, AND/OR ELECTRICAL SHOCK. ONLY PERSONS WHO CAN UNDERSTAND AND FOLLOW THE INSTRUCTIONS SHOULD USE OR SERVICE THIS HEATER. IF YOU NEED ASSISTANCE OR HEATER INFORMATION SUCH AS AN INSTRUCTIONS MANUAL, LABELS, ETC. CONTACT THE MANUFACTURER.

WARNING

NOT FOR HOME OR RECREATIONAL VEHICLE USE

WARNING

YOUR SAFETY IS IMPORTANT TO YOU AND TO OTHERS, SO PLEASE READ THESE INSTRUCTIONS BEFORE YOU OPERATE THIS HEATER

- **THE ELECTRICAL SYSTEM TO WHICH THE APPLIANCE IS CONNECTED MUST COMPLY WITH CURRENT LEGISLATION. INSTALLATION REQUIRES A RESIDUAL CURRENT CIRCUIT BREAKER (RCCB) IN THE MAIN ELECTRICAL DISTRIBUTION BOARD.**
- **UNPLUG THE APPLIANCE BEFORE PERFORMING ANY MAINTENANCE OPERATIONS.**
- **ALWAYS CHECK THE POWER CABLE BEFORE USING THE APPLIANCE. IT MUST NOT BE BENT, TAUT, STRETCHED, CRUSHED OR ANY WAY DAMAGED.**
- **THE POWER CABLE MUST BE REPLACED BY QUALIFIED PERSONNEL ONLY. USE AN ORIGINAL POWER CABLE ONLY WITH A 3-PIN APPROVED PLUG.**
- **THE FRONT OUTLET IS VERY HOT DURING OPERATION. DO NOT TOUCH! BURN DANGER.**

2. PRODUCT DESCRIPTION

Diesel or Kerosene direct-fired mobile/portable space heater with open combustion chamber and indirect fired mobile/portable space heater with close combustion chamber.

3. TECHNICAL SPECIFICATIONS

Model	PIN HK070FWI
Heat Input* [kW] [Hrs]	20
Air Flow Rating [m ³ /h]	600
Fuel Type	Diesel - Kerosene
Fuel Consumption [kg/h]	1.65
Voltage [V/Hz]	AC240V/50
Air Pressure Setting [bar]	0.38
Current Rating [A]	1.1
Electrical power Rating [W]	230
Fuse Rating	T3.15A
Efficiency* [%]	78
Dimensions	
Net Weight (kg)	21.3
Length (mm)	840
Width (mm)	490
Height (mm)	690
Tank Capacity (l)	38
Operating Range (h)	~19
Standard Accessories	
Fuel Gauge	yes
Handle	1
Ambient thermostat	built-in
Malfunction detection signal	built-in

* Based on Gross Calorific Value [Hrs]

*Based on dedicated setting for standard condition (atmospheric pressure 1020 kPa and Temperature 20 °C).

4. ASSEMBLING INSTRUCTIONS

Extract the heater from its carton. If the unit is anyhow damaged, do not use it and contact your dealer.

The following accessories are supplied in the shipping carton.




Fig.1



Pos.	Description	Qty
A	Handle	1
B	Screw	8
C	Spring washer	8
D	Plain washer	8
E	Feet pipe	1
F	Nut M5	8
G	Nut M12	2
H	Wheel	2
I	Plain washer ø12	2
J	Wheel shaft	1
K	Cotter	2

To assemble the heater, proceed as follows (see Fig. 1):

1. Insert the wheel shaft J to the corresponding hole of feet pipe E, insert the cotter K to the corresponding holes, put plain washer I to the two sides of shaft, slide the wheel H over the wheel shaft J, screw the nut G to fix the wheel on the shaft.
2. Put the heater body on the low tube frame assembly, make sure the 4 holes of handle A point towards the corresponding 4 holes on the low tube frame respectively.
3. Using the screw B, Spring washer C, plain washer D and nut F to fix the low tube frame assembly and handle to the tank.

5. INSTALLATION INSTRUCTIONS

- Position the heater on a flat, level, non-flammable, solid surface.
- The exhaust gases are very harmful for people and animals when released in a closed space without ventilation.
- Indirect-fired heaters while used in indoor installation, must be connected to an exhaust pipe to vent the products of combustion outside. To maintain an adequate Oxygen rate, a minimum of 80 m³/h airflow from outside must be ensured.
- For indirect fired heaters: connect the heater to a chimney or to an exhaust duct L. To get a proper draught in the chimney the exhaust gas path must rise. Avoid any elbows and bends in the first part of the exhaust ducts for at least 3 m.



- Only install the heater in normal upright position.
- Do not place the heater near walls, corners or low ceilings.
- Do not place the heater below a socket outlet.
- Do not place the heater on moving vehicles or where it can tip over.
- Keep the heater away from flammable, combustible, explosive or corrosive materials.
- Keep the heater away from curtains or similar materials that could block the air inlet and outlet.
- Never block or restrict the air inlet and outlet for any reason.
- Keep the power cable away from heat sources, sharp edges, cutting and moving parts.
- Do not expose directly to the weather or to excessive humidity.
- Do not place the heater in the immediate surroundings of a bath, shower or swimming pool.

- Follow general and special fire safety regulations in force in all fields of applications. In any case ensure the following minimum safety clearances from materials or objects in the surroundings of the heater:
 - Side: 1 m
 - Air inlet side: 1 m
 - Top: 1.5 m
 - Hot air outlet side: 3 m
 - Floor: 0 m
- Floors and ceilings must be made of fireproof materials in the place where the heater is operated.
- Do not connect direct-fired heaters to air ducts.

6. INSTRUCTIONS FOR USE

6.1. Start-up

Fill tank with clean fuel. Only use Diesel or Kerosene.

The fuel gauge on top of the tank allows to check fuel level.

Connect the power cord plug to a AC240 V 50 Hz earthed electrical supply system. **Earthing is mandatory.**

Model

Having completed the “startup” phase, the left display window shows “--”, the right display window shows ambient temperature value.

Push the power switch to “on” position.

The default temperature setting is 20°C, it will be showed on the left display window.

If the ambient temperature is lower than default temperature, waiting for 7 seconds, the heater will start.

If the ambient temperature is higher than default temperature, turn thermostat control knob to desired temperature, waiting for 7 seconds, the heater will start.

COLD START-UP: at low temperature keep the air vent hole (see Fig. 5) closed by a finger during ignition to make start-up easier.

ABNORMAL OPERATION: in case of malfunction (flame failure, reduced air flow, bad combustion, etc.) the heater stops, and THE LOCK-OUT MODE code will be showed on the display window-see troubleshooting.

6.2. Manual reset/restart

If the heater is in lock-out mode, check and remove the cause of lock-out before restarting the heater. To reset, turn the ON/OFF switch to 0 and then (after 4 sec) again to I. In case of repeated malfunction, call technical service. Turning the thermostat control knob will NOT reset the heater.

6.3. Shut-down

Move switch to "OFF" (O) position. The post-ventilation phase will cool down the combustion chamber for 90 seconds. Unplug the unit when not used for a long time.

- **Never disconnect the heater from mains to stop it while in operation. Always allow the cooling sequence to be completed, otherwise the residual heat could damage internal components.**
- **Do not cover the heater. Do not block the air inlet and outlet.**
- **The heater outlet is very hot during operation and after use. Do not touch! Use personal protecting equipment if needed.**
- **Children should be supervised to ensure that they do not play with the appliance.**
- **The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.**
- **Unplug the heater before moving it. Never pull the cable to unplug or move the unit.**
- **Do not leave the heater unattended when in use.**
- **Never use the appliance with wet hands or when either the heater or the power cable is wet.**
- **If the supply cable is damaged, it must be replaced by the manufacturer, by a service agent or a similar qualified person.**

7. CLEANING, MAINTENANCE AND STORAGE

Regularly wipe the enclosure using a soft sponge or cloth. For very dirty parts, use a sponge wetted with lukewarm water and a mild detergent, then dry using a clean cloth.

Keep air inlet and fan free from dust and dirt. To clean inner parts, gently blow compressed air through air inlet.

Regularly inspect the power cable: if worn, cracked or damaged have it replaced by technical service.

Before storing the heater, make sure it is perfectly cool and dry. Cover the unit with a plastic bag, put it in its packing box and store it in a dry, ventilated place.

- **Before starting any maintenance task, shut down, unplug and let the heater cool down for at least 15 minutes.**
- **Do not attempt any electrical repair yourself. If the heater needs service or repair, contact a qualified technician.**
- **Do not use a faulty unit unless a qualified technician has inspected and repaired it.**
- **When cleaning, make sure that water does not enter the unit.**
- **Do not open the enclosure to clean the inner parts. Do not spray water into the heater.**
- **Never use solvents, gasoline, toluene and similar aggressive chemicals to clean the heater.**

The following checks BY QUALIFIED PERSONNEL ONLY are recommended before every seasonal use:

Nozzle

Carefully unscrew nozzle from nozzle fitting. Blow compressed air through nozzle orifice to free it from dirt. Replace nozzle if necessary.

Air Filters

Clean air filters. Remove filter end cover (11), wash air intake filter (10) using a light detergent and dry it thoroughly before re-installing. Replace air delivery filter (9) once a year (Fig.2)




Fig.2

Ignition Electrodes

Clean, adjust and if necessary, replace ignition electrode. For electrode gaps see Fig. 3-4 (dimensions in mm).




Fig.3




Fig.4

Compressor pressure adjustment (Fig. 5)

- **The compressor pressure is factory set and must be checked and adjusted by qualified technicians only. Tampering with the unit may be dangerous.**

Remove pressure gauge cap. Connect a pressure gauge on the pressure measuring port on the rear guard. Start heater and read air pressure value. If necessary, adjust pressure to the correct value turning the adjusting screw (the air vent hole in the adjusting screw middle) clockwise to increase, anticlockwise to decrease the pressure:




Fig.5

Model
PIN HK070FWI


Air Pressure (bar)
0.38

HIGH ALTITUDE INSTALLATION: Due to lower oxygen rate with reference to high altitude installation on sea level, it may be necessary to reduce the compressor pressure (fig. 5). This setting adjustment can be necessary to maintain a good combustion due to lack of Oxygen.

Electrical

Inspect cables, electrical parts and connections.

8. WIRING DIAGRAM



Wiring diagram for PIN HK070FWI

8. TROUBLESHOOTING

PROBLEM	CAUSE	REMEDY
Motor does not start. E1 displayed on the screen.	No power or low voltage	Check power line and voltage
		Check fuse and replace if necessary
	Faulty or damaged power cord	Check and replace if needed.
	Faulty motor/capacitor	Check and if necessary, replace.
	Lock-out of appliance due to previous overheating.	Detect the cause of overheating. Shut the appliance down. Check air inlet and outlet. Wait some minutes and restart the appliance

PROBLEM	CAUSE	REMEDY
E2 displayed on the screen	The temperature probe is faulted. or the connector for temperature probe is loose	Check and replace if the temperature probe if needed. Check and replace the PCB if needed
Motor runs, but the heater does not ignite and locks out after a short time	Empty fuel tank, dirty or wrong fuel	Remove wrong or dirty fuel. Fill the tank with clean Diesel or kerosene.
	Fuel filter clogged	Clean or replace fuel filter
E1 displayed on the screen	Air leaks in oil line	Check hoses, tighten connections, if necessary, replace
	Burner nozzle clogged	Clean nozzle blowing compressed air, replace if necessary
	Fuel viscosity increased at low temperature	Mix Diesel with 10-20% kerosene
Flames come out of flue outlet.	Insufficient airflow into combustion chamber	Check air inlet, fan, motor.
	Compressor pressure too high	Check air pressure, adjust if needed
Heater stops during operation.	The room temperature set on room thermostat has been reached	Normal operation To start turn the temperature control knob clockwise on a higher setting
Heater stops during operation. E1 displayed on the screen	Flame failure.	Check and remove the cause(s) of malfunction. To reset, turn On/Off switch to 0 and then to I
	Bad combustion	
	Reduced airflow	Call technical service if the problem persists
	Overheating	
LC displayed on the screen	Failed 3 times for igniting will lock the PCB and stop working	With electricity on, it will be unlocked after 3 times power switch to ON in 10 seconds;

Distributed in Australia by



CONTACT DETAILS

B.A.R Group P/L
15 Hudson Place,
Mulgrave, NSW, Australia 2756
Phone: 02 4577 2144
www.bargroup.com.au

Distributed in New Zealand by



POWER EQUIPMENT

CONTACT DETAILS

BE Pressure Supply
541D Te Rapa Road, Te Rapa,
Hamilton 3200, New Zealand
Phone: 07 849 0000
www.bepressure.co.nz

Errors and omissions excepted.
Specifications and performance may change.