



柴油机零部件图册

PARTS CATALOGUE

LC178F(D)

LC186F(D)



Version number: LC/LT-2017-A

隆鑫通用动力股份有限公司

LONCIN MOTOR CO.,LTD.

零件目录使用说明 (Instruction for use of parts catalogue)

本零件目录是根据2017年1月所能得到的最新资料编制而成的。

This parts catalogue was prepared based on the latest information available as of January 2017.

请注意2017年1月以后本零部件目录的修订通知。

See the parts catalogue news for any revision that is made after January 2017.

当订购零件时，一定要明确指出其零件编号。

Always specify the part number when ordering a part.

注意本零件目录所给出的图形可能与实际零件外形有所不同。


Note that the illustrations can differ from the actual parts in shape.

当需要对零部件目录的内容进行更改或增加时，本公司将在适当的时间出版修订版，为保证在任何时候都可以使用到最新版本的零部件目录建议拥有最新的修订版本。如果要检查修订版本是否已经发行，请直接与LONCIN联系。

When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your LONCIN distributor.


示例 (Example)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
				LC178F	LC178FD	LC186F	LC186FD
5	130160021-T270	连杆体	Connecting rod	1	1		
	130160023-T490	连杆体	Connecting rod			1	1
6	110280007-T270	轴瓦	Shell, crank pin	2	2		
	110280009-T490	轴瓦	Shell, crank pin			2	2
7	130290287-T270	曲轴部件	Crankshaft comp.	1	1		
	130290388-T490	曲轴部件	Crankshaft comp.			1	1
8	380620095-T270	半圆键	Woodruff key	1	1	1	1




曲轴箱体组件 (Crankcase Assy.)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	110260051-0001	110260051-T270	密封螺塞 M16×16	Seal plug M16×16	2	2	2	2
2	380450830-0001	380450830-T270	平垫圈 φ16.5×φ22.5×1.8	Washer φ16.5×φ22.5×1.8	2	2	2	2
3	110810208-0001	110810208-T271	曲轴箱体	Crankcase	1	/	/	/
	110810126-0001	110810126-T270	曲轴箱体	Crankcase	/	1	/	/
	110810244-0001	110810244-T491	曲轴箱体	Crankcase	/	/	1	/
	110810169-0001	110810169-T490	曲轴箱体	Crankcase	/	/	/	1
4	380600169-0001	380600169-T270	定位销 8×16	Pin 8×16	2	2	2	2
5	110690051-0001	110690051-T270	机油尺组合	Cap assy,oil filler	1	1	1	1
6	380630002-0001	380630002-0001	轴承 6203	Bearing 6203	1	1	1	1
7	380840792-0001	380840792-T270	密封圈	Seal	1	1	1	1
8	380650337-0001	380650337-T110	油封 35×52×7	Oil seal 35×52×7	1	1	/	/
	380650574-0001	380650574-T490	油封 40×52×7	Oil seal 40×52×7	/	/	1	1
9	130240004-0001	130240004-T270	曲轴左轴承压板	Plate,Bearing	2	2	2	2
10	380140040-0005	380140040-0005	六角头法兰面螺栓 M8×16	Bolt, flange M8×16	2	2	2	2




曲轴箱体组件 (Crankcase Assy.)

[illegible]




曲轴箱盖 (Crankcase cover)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	380140051-0005	380140051-0005	六角头法兰面螺栓 M8×35	Bolt, Flange M8×35	13	13	14	14
2	380650336-0001	380650336-T080	油封 30×46×8	Oil seal 30×46×8	1	1	/	/
	380650575-0001	380650575-T490	油封 35×50×8	Oil seal 35×50×8	/	/	1	1
3	110260053-0001	110260053-T271	密封螺塞 1/8-27NPTF	Seal plug 1/8-27NPTF	1	/	1	/
4	150290021-0001	150290021-T270	机油滤网	Oil filler assy.	1	1	1	1
5	110690051-0001	110690051-T270	机油尺组合	Cap assy, oil filler	1	1	1	1
6	380070288-0001	380070288-0001	六角头螺栓 M12×16	Bolt M12×16	1	1	1	1
7	380450516-0001	380450516-T110	平垫圈 φ12×φ20×2	Washer φ12×φ20×2	1	1	1	1
8	381150514-0001	381150514-T270	压簧	Compress spring	1	1	1	1
9	380640016-0001	380640016-0001	钢球	Ball	1	1	1	1
10	110820064-0001	110820064-T270	曲轴箱盖	Crankcase cover	1	1	/	/
	110820187-0001	110820187-T495	曲轴箱盖	Crankcase cover	/	/	1	1
11	150010068-0001	150010068-T270	机油泵部件	Pump oil	1	1	/	/
	150010101-0001	150010101-T490	机油泵部件	Pump oil	/	/	1	1




曲轴箱盖 (Crankcase cover)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
12	380630002-0001	380630002-0001	轴承 6203	Bearing 6203	1	1	1	1
13	380780123-0001	380780123-T270	管接头	Pipe inlet oil	1	1	1	1
14	150040029-0001	150040029-T270	油泵盖	Plate,Oil pump	1	1	/	/
	150040031-0001	150040031-T490	油泵盖	Plate,Oil pump	/	/	1	1
15	380140003-0005	380140003-0005	六角头法兰面螺栓 M6×20	Bolt,Flange M6×20	4	4	3	3
16	171750018-0001	171750018-T270	调速齿轮部件	Governor Gear Assy.	1	1	/	/
	171750040-0001	171750040-T490	调速齿轮部件	Governor Gear Assy.	/	/	1	1
17	110830042-0001	110830042-T270	曲轴箱盖密封垫	Gasket,Crankcase cover	1	1	/	/
	110830047-0001	110830047-T490	曲轴箱盖密封垫	Gasket,Crankcase cover	/	/	1	1
18	130280003-0001	130280003-T490	曲轴右轴承压板	Plate,Bearing	/	/	1	1
19	380140001-0006	380140001-0006	六角头法兰面螺栓 M6×112	Bolt, flange	/	/	1	1



气缸头 (Cylinder Head Assy.)


序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	380140102-0004	380140102-0004	六角头法兰面螺栓 M6×25	Bolt, Flange M6×25	4	4	4	4
2	120220040-0001	120220040-T270	气缸头盖组合	Cylinder head cover comp.	1	1	/	/
	120220046-0001	120220046-T490	气缸头盖组合	Cylinder head cover comp.	/	/	1	1
3	120250031-0001	120250031-T270	气缸头盖密封垫	Gasket, Cylinder head cover	1	1	/	/
	120250036-0001	120250036-T490	气缸头盖密封垫	Gasket, Cylinder head cover	/	/	1	1
4	380140596-0001	380140596-0001	六角头螺栓 M10×1.25×90	Bolt, Head M10×1.25×90	4	4	/	/
	380140554-0001	380140554-0001	六角头螺栓 M10×1.25×95	Bolt, Head M10×1.25×95	/	/	4	4
5	120080528-0001	120080528-T271	气缸头	Head comp, Cylinder	1	1	/	/
	120080724-0001	120080724-T494	气缸头	Head comp, Cylinder	/	/	1	1
6	120150190-0001	120150190-T270	气缸头密封垫	Gasket, Cylinder 0.5	1	1	/	/
	120150173-0001	120150173-T490	气缸头密封垫	Gasket, Cylinder 0.5	/	/	1	1
7	380600167-0001	380600167-T270	定位销 4×11	Pin 4×11	2	2	2	2
8	380140004-0004	380140004-0004	六角头法兰面螺栓 M8×20	Bolt, Flange M8×20	1	1	1	1
9	120550005-0001	120550005-T270	吊耳	Lifting eye	1	1	1	1
10	380140051-0005	380140051-0005	六角头法兰面螺栓 M8×35	Bolt, Flange M8×35	/	/	1	1



曲柄连杆机构 (Connecting rods and Crankshaft)


序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	130070138-0001	130070138-T270	活塞环组合	Ring set	1	1	/	/
	130070167-0001	130070167-T490	活塞环组合	Ring set	/	/	1	1
2	380560092-0001	380560092-T270	钢丝挡圈	Clip, piston pin	2	2	/	/
	380560103-0001	380560103-T490	钢丝挡圈	Clip, piston pin	/	/	2	2
3	130030157-0001	130030157-T270	活塞	Piston	1	1	/	/
	130030186-0001	130030186-T490	活塞	Piston	/	/	1	1
4	130060058-0001	130060058-T270	活塞销	Pin, piston	1	1	/	/
	130060062-0001	130060062-T490	活塞销	Pin, piston	/	/	1	1
5	130150083-0001	130150083-T270	连杆	Conn rod assy	1	1	/	/
	130150089-0001	130150089-T490	连杆	Conn rod assy	/	/	1	1
6	110280007-0001	110280007-T270	轴瓦	Shell, crank pin	2	2	/	/
	110280009-0001	110280009-T490	轴瓦	Shell, crank pin	/	/	2	2
7	130290287-0001	130290287-T270	曲轴部件	Crankshaft comp.(A)	1	1	/	/
	130290586-0001	130290586-T490	曲轴部件	Crankshaft comp.(A)	/	/	1	1

[illegible]




配气机构 (Valve Train)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	140450042-0001	140450042-T270	气门摇臂组合	Rocker Arm Assy.Intake	1	1	/	/
2	140450043-0001	140450043-T270	气门摇臂组合	Rocker Arm Assy.Exhaust	1	1	/	/
3	140320007-0001	140320007-T270	气门调整帽	Cap, Exh. Valve	2	2	/	/
4	140380036-0001	140380036-T270	气门弹簧座	Seat, valve	2	2	/	/
5	140390026-0001	140390026-T270	气门锁夹	Lock clamp,Valve	4	4	/	/
6	140340035-0001	140340035-T270	气门内弹簧	Valve spring	2	2	/	/
7	140400022-0001	140400022-T270	挡油罩	Seal valve stem	2	2	/	/
8	140360014-0001	140360014-T270	气门内弹簧座圈	Seat bottom,Valve	2	2	/	/
9	500550040-0001	500550040-T270	气门套件	Valve kit	1	1	/	/
10	140020145-0001	140020145-T270	凸轮轴组合	Camshaft comp.	1	1	/	/
11	140720008-0001	140720008-T270	推杆限位板	Plate guide valve	1	1	/	/
12	140670024-0001	140670024-T270	挺杆组合	Push rod comp.	2	2	/	/
13	140690020-0001	140690020-T270	挺柱	Tappet valve	2	2	/	/




配气机构 (Valve Train)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	140450072-0001	140450072-T490	气门摇臂组合	Rocker Arm Assy.Intake	/	/	1	1
2	140450073-0001	140450073-T490	气门摇臂组合	Rocker Arm Assy.Exhaust	/	/	1	1
3	140020175-0001	140020175-T490	凸轮轴组合	Camshaft comp.	/	/	1	1
4	140380040-0001	140380040-T490	气门弹簧座	Seat, valve	/	/	2	2
5	140390015-0001	140390015-T11D	气门锁夹	Lock clamp,Valve	/	/	4	4
6	140340040-0001	140340040-T490	气门内弹簧	Valve spring	/	/	2	2
7	140400012-0001	140400012-T110	挡油罩	Seal valve stem	/	/	2	2
8	140360014-0001	140360014-T270	气门内弹簧座圈	Seat bottom,Valve	/	/	2	2
9	500550100-0001	500550100-T490	气门套件	Valve kit	/	/	1	1
10	140540029-0001	140540029-T490	摇臂支撑座	Rocker, Bottom	/	/	2	2
11	140510062-0001	140510062-T490	气门摇臂轴	Valve Rocker Shaft	/	/	2	2
12	140670055-0001	140670055-T490	挺杆组合	Push rod comp.	/	/	2	2
13	140690023-0001	140690023-T490	挺柱	Tappet valve	/	/	2	2





电器系统 (Electrical System)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	270020227-0001	270020227-T271	磁电机转子部件	Flywheel	1	/	/	/
	270020182-0001	270020182-T270	磁电机转子部件	Flywheel	/	1	/	/
	270020250-0001	270020250-T491	磁电机转子部件	Flywheel	/	/	1	/
	270020213-0001	270020213-T490	磁电机转子部件	Flywheel	/	/	/	1
2	270360060-0001	270360060-T270	起动机部件	Start motor	/	1	/	1
3	270190013-0001	270190013-T270	充电线圈部件	Stator assy.	/	1	/	1
4	380140102-0004	380140102-0004	六角头法兰面螺栓 M6×25	Bolt, Flange M6×25	/	3	/	3
5	270910010-0001	270910010-T270	调压整流器支架	Regulator plate	/	1	/	1
6	271380036-0001	271380036-T270	点火开关支架	Bracket Switch	/	1	/	/
	271380040-0001	271380040-T490	点火开关支架	Bracket Switch	/	/	/	1
7	270880146-0001	270880146-T270	调压整流器	Regulator	/	1	/	1
8	380140215-0003	380140215-0003	六角头法兰面螺栓 M6×14	Bolt, Flange M6×14	/	5	/	5
9	380140126-0004	380140126-0004	六角头螺栓 M10×40	Bolt M10×40	/	2	/	2
10	283690003-0001	283690003-T372	油位报警器	Sensor Oil Pressure	/	1	/	1




手起动器组件 (Pullstart Assy)


序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	160180027-0001	160180027-T270	叶轮	Fan	1	1	/	/
	160180030-0001	160180030-T490	叶轮	Fan	/	/	1	1
2	660880002-0001	660880002-T270	叶轮压板	Plate, Fan	1	1	1	1
3	193590019-0001	193590019-T270	起动盘	Cup Starter	1	1	1	1
4	380450702-0001	380450702-0001	平垫圈 $\phi 13 \times \phi 38 \times 3.5$	Washer $\phi 13 \times \phi 38 \times 3.5$	1	1	1	1
5	380140457-0001	380140457-0001	六角头螺栓M12 $\times$ 12.5 $\times$ 35	BoltM12 $\times$ 12.5 $\times$ 35	1	1	1	1
6	380840758-0001	380840758-T270	密封圈	Seal	1	1	1	1
7	193490156-0001	193490156-T270	手起动组件	Pull start Assy	1	1	/	/
	193490200-0001	193490200-T490	手起动组件	Pull start Assy	/	/	1	1
8	380450828-0001	380450828-0001	平垫圈 $\phi 6 \times \phi 18 \times 1.2$	Washer $\phi 6 \times \phi 18 \times 1.2$	4	4	4	4
9	380140095-0005	380140095-0005	六角头法兰面螺栓M6 $\times$ 30	Bolt, Flange M6 $\times$ 30	4	4	4	4



空滤器 (Air cleaner) Oil


序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	380180156-0001	380180156-T270	双头螺栓 M6/8×32.5	Stud M6/8×32.5	2	2	/	/
	380180098-0001	380180098-T040	双头螺栓 M8×34	Stud M8×34	/	/	2	2
2	183000001-0001	183000001-T270	进气口密封垫	Gasket,In.	1	1	/	/
	183000002-0001	183000002-T490	进气口密封垫	Gasket,In.	/	/	1	1
3	180420579-0001	180420579-T270	进气管	Intank Pipe	1	1	/	/
	180420620-0001	180420620-T490	进气管	Intank Pipe	/	/	1	1
4	380370066-0001	380370066-0001	六角法兰面螺母 M6	Nut M6	5	5	/	/
	380370074-0002	380370074-0002	六角法兰面螺母 M8	Nut M8	/	/	4	4
5	183000003-0001	183000003-T270	进气口密封垫	Gasket,In.	1	1	/	/
	183000004-0001	183000004-T490	进气口密封垫	Gasket,In.	/	/	1	1
6	180010089-0001	180010089-T270	空滤器组件	Air cleaner assy	1	1	/	/
	180010102-0001	180010102-T490	空滤器组件	Air cleaner assy	/	/	1	1
7	180090071-T270	180090071-T270	空滤器密封条	Seal	1	1	1	1
8	180130248-0001	180130248-T270	空滤器滤芯	Filter	1	1	/	/

[illegible]




消声器 (Muffler)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	380140102-0004	380140102-0004	六角头法兰面螺栓 M6×25	Bolt, Flange M6×25	4	4	3	3
2	380450828-0001	380450828-0001	平垫圈φ6×φ18×1.2	Washer φ6×φ18×1.2	4	4	3	3
3	160190051-0001	160190051-T270	空气导流罩	Air conduction cover	1	1	/	/
	160190059-0001	160190059-T490	空气导流罩	Air conduction cover	/	/	1	1
4	380340005-0005	380340005-0005	六角螺母 M8	Nut M8	2	2	2	2
5	380180098-0001	380180098-T040	双头螺栓 M8×34	Stud M8×34	2	2	2	2
6	180660064-0001	180660064-T270	消声器密封垫	Gasket, Muffler	1	1	/	/
	180660072-0001	180660072-T490	消声器密封垫	Gasket, Muffler	/	/	1	1
7	380140004-0004	380140004-0004	六角头法兰面螺栓 M8×20	Bolt, Flange M8×20	2	2	2	2
8	180571299-0001	180571299-T270	消声器	Muffler	1	1	/	/
	180571505-0001	180571505-T490	消声器	Muffler	/	/	1	1




燃油系统 (Fuel Sysstem)


序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	170010030-0001	170010030-T270	燃油滤清器	Fuel filter	1	1	1	1
2	660310019-0001	660310019-T270	(燃油滤网)密封垫片	Seal,Fuel net	1	1	1	1
3	170870089-0001	170870089-T270	油箱盖	Cap Comp.	1	1	1	1
4	170500800-0001	170500800-T270	油箱	Fuel tank	1	1	/	/
	170500938-0001	170500938-T490	油箱	Fuel tank	/	/	1	1
5	171020032-0001	171020032-T270	油开关密封垫	Seal,Fuel Tap	1	1	1	1
6	170980092-0001	170980092-T270	油开关部件	Fuel Tap Assy.	1	1	1	1
7	380370066-0001	380370066-0001	六角法兰面螺母 M6	Nut,Flange M6	7	7	7	7
8	380960198-0001	380960198-T270	卡箍组合 Φ13	Lathe dog comp.Φ13	2	2	2	2
9	380750486-0001	380750486-T270	油管	Vitta	1	1	/	/
	380750661-0001	380750661-T490	油管	Vitta	/	/	1	1
10	380140004-0004	380140004-0004	六角头法兰面螺栓 M8×20	Bolt,Flange M8×20	2	2	2	2
11	301560017-0001	301560017-T270	油箱支撑架 (下)	Fuel tank, bracket	1	1	1	1
12	170700141-0001	170700141-T270	油箱减震胶垫	Bush Rubber	4	4	4	4



燃油系统 (Fuel System)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
13	110260056-0001	110260056-T270	密封螺塞 M12×1.25×14	Seal plug M12×1.25×14	1	1	1	1
14	380450916-0001	380450916-T270	平垫圈 φ12.5×φ20×2	Washer φ12.5×φ20×2	1	1	1	1
15	380960170-0002	380960170-0002	卡箍组合 Φ9	Lathe dog comp.Φ9	2	2	2	2
16	380750487-0001	380750487-T270	油管	Vitta	1	1	1	1
17	380180138-0001	380180138-T270	双头螺栓 M6×54	Stud M6×54	2	2	2	2
18	174180001-0001	174180001-T270	喷油器压板	Injector,Plate	1	1	1	1
19	173010004-0001	173010004-T270	喷油器	Injector	1	1	/	/
	173010006-0001	173010006-T490	喷油器	Injector	/	/	1	1
20	380450829-0001	380450829-T270	平垫圈 φ7.3×φ15×0.5	Washer φ7.3×φ15×0.5	1	1	1	1
21	380750471-0001	380750471-T270	油管	Vitta	1	1	/	/
	380750529-0001	380750529-T490	油管	Vitta	/	/	1	1
22	380180137-0001	380180137-T270	双头螺栓 M6×38	Stud M6×38	2	2	2	2
23	380180145-0001	380180145-T270	双头螺栓 M6×31	Stud M6×38	1	1	1	1
24	174160001-0001	174160001-T270	喷油泵盖板	Fuel Pump,Plate	1	1	1	1

[illegible]



调速系统 (Governor System)

序号 No.	零部件图号 Part No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)			
					LC178F	LC178FD	LC186F	LC186FD
1	380140215-0003	380140215-0003	六角头法兰面螺栓 M6×14	Bolt, Flange M6×14	2	2	2	2
2	171340029-T270	171340029-T270	油门控制手柄	Knob control	1	1	1	1
3	380350008-0001	380350008-0001	非金属嵌件六角锁紧螺母 M6	Nonmetal hexagon nuts M6	1	1	1	1
4	171580019-0001	171580019-T270	调速控制组件	Control assy	1	1	/	/
	171580022-0001	171580022-T490	调速控制组件	Control assy	/	/	1	1
5	174230001-0001	174230001-T270	油量调节组合	Fuel stop assy.	1	1	1	1
6	381160150-0001	381160150-T270	扭簧	Torsional spring	1	1	1	1
7	381140478-0001	381140478-T270	拉簧	spring	1	1	1	1
8	171600042-0001	171600042-T270	调速弹簧	Spring, Governor	1	1	/	/
	171600051-0001	171600051-T490	调速弹簧	Spring, Governor	/	/	1	1
9	380650377-0001	380650377-T240	油封 8×14×5	Oil seal 8×14×5	1	1	1	1
10	380450592-0001	380450592-T240	平垫圈φ8.5×φ15.8×2	Washer φ8.5×φ15.8×2	2	2	2	2
11	194530005-0001	194530005-T270	拨叉组合	Fork	1	1	/	/
	194530008-0001	194530008-T490	拨叉组合	Fork	/	/	1	1



隆鑫通用动力股份有限公司

Loncin motor co., Ltd.

详细地址：重庆市九龙坡区九龙工业园区华龙大道99号

Add: No. 99 Hualong Road, Jiulongpo District, Chongqing, China

Tel: 86 23 8980 5678/86 23 8980 8505

Fax: 86 23 8906 7566

Email: service@loncinengine.com

Website: www.loncinengine.com

PRINTED IN CHINA