



PARTS BREAKDOWN



Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	Engine	1	19	Handwheel	3
2	Support stand	1	20	Discharge guard	1
3	Stand pad	2	21	End Cap	4
4	Flange Bolt M6x16	5	22	Damper	1
5	Guard	1	23	Washer 8	15
6	Rubber cover	1	24	Spring washer 8	15
7	Flange nut M6	15	25	Bolt M8x20	4
8	Retainer hopper guard	1	26	Flange Bolt M6x35	4
9	Flange nut M8	24	27	Hopper	1
10	Side Clute	1	28	Handle	1
11	Socket Cap Screw M6x40	2	29	hopper Guard	1
12	Washer 6	8	30	Retainer hopper guard	1
13	Flange Bolt M8x60	4	31	Flange Bolt M6x20	4
14	Flange	2	32	Flange hopper guard	1
15	Wheel	2	33	Bolt M6x16	3
16	Spring pin	4	34	Suspender	1
17	Bag	1	35	Backing plate	1
18	Spring washer 6	6			


Parts Breakdown – Engine and Rotor Group

Part No.	Description	Q'ty
1	Engine	1
2	Flange	2
3	Engine plate	1
4	Spring washer 8	4
5	Hex bolt	4
6	Key parallel pin	1
7	Bearing spacer	1
8	Rotor assembly kit	1
9	Washer	1
10	Hex head bolts	1
11	Washer 8	4



Parts Breakdown – Rotor Group

Part No.	Description	Q'ty
1	Socket head cap screw M10x50	4
2	Spring washer 10	4
3	Washer 10	4
4	Y hammer	4
5	Bearing sleeve	4
6	Knives plate	1
7	Locknut M8	4
8	Spring washer 8	4
9	Washer 8	4
10	Knife	2
11	Screw	4



PARTS BREAKDOWN - CHIPPER HOUSING GROUP

Part No.	Description	Q'ty
1	Engine plate	1
2	Rotor assembly kit	1
3	Rotor house	1
4	Chipper back cover	1
5	Hex bolt M6x16	1
6	Flange nut M8	18
7	Vacuum inlet cover	1
8	Hex bolt M8x16	3
9	Spring washer	3
10	Washer	3
11	Wheel rack	1
12	Flage nut M6	1

